

Basic / Footmaster Footrest

by
Kondator



Basic Footrest is unique and stable, which is adjusted with the pedal to the desired height. The spring loaded automatic lift the footplate quickly and easily without any effort. Adjust footplate angle with your feet, depending on leg length and seat height.

Basic should be obvious at all sit & stand desks. Always practical and restful, relieving tension in sitting and standing posture.

Who wants to "hang around the bar" a full working day, without lifting your feet and find a comfortable position?



Part no 642-9520 Basic Footrest.

Tip! Turn Basic footrest and drag it slightly closer to the work chair. Now you have a "really nice recliner," with the legs at a comfortable height on the footrest.

Take your feet to a new level!

A good footrest should always give a firm support for the feet, regardless of its height and position in the workchair. And of course, easily adjustable to the desired height and angle of the footrest.



Part no 642-3121 Footmaster Footrest.

Foot Master Footrest have an original principle of a self-adjusting base plate. Many followers have been, however, no better and equally affordable.

Foot Master is always firmly on the floor, and foot plate is always as easy to adjust as needed.

SPECIFICATIONS

Basic

- Vertical adjustable footrest by pedal.
- Spring-loaded operation
- Stepless tiltable
- Sturdy construction standing firmly on the floor
- Dimensions: Width 420mm, Depth 315mm, Height 80-290 mm

Foot Master

- Foot adjustment of footplate
- Stepless tiltable
- Stands firmly on the floor
- Dimensions: Width 475 mm, Depth 300 mm, height 50-90 mm