# KRAMER





# PT-871/2xr-KIT Quick Start Guide

This guide helps you install and use your PT-871xr, PT-872xr for the first time.

Go to www.kramerav.com/downloads/PT-871xr to download the latest user manual and check if firmware upgrades are available.

### Step 1: Check what's in the box

- ☑ PT-871xr, PT-872xr HDMI 4K Line Transmitter/Receiver
- 4 Rubber feet (per device)
- ☑ 1 Bracket set (per device)

1 Power adapter and cord


 $\mathbf{Y}$ 1 Quick start guide


#### **IMPORTANT NOTICE!**





We highly recommend using only Kramer UNIKAT cables with these products. If using 3rd party shielded CAT-6A cables, both ends of the shield must be soldered to the connectors for the products to function properly. Do not use any jumpers, unshielded wall plates or midspan cable connections. These extenders are not compatible with HDBaseT technologies. Prior to signal extension, ensure that the extension line cable is lying straight and not coiled.

#### Get to know your PT-871xr, PT-872xr










#	Feature		Function		
1		IN	Lights when an active s	ource is connected to HDMI IN on the PT-871xr.	
2	LED Indicators	OUT	Lights when an active acceptor is connected to HDMI OUT on the PT-872xr.		
3		ON	Lights when power is connected to the device.		
4	HDMI IN Connector (PT-871xr)		Connect to an HDMI source.		
	HDMI OUT Connector (PT-872xr)		Connect to an HDMI acceptor.		
5	SETUP DIP-switches		Set the operation DIP-switches. Both DIP-switches are set to OFF (up) by default.  i Always set the DIP-switches identically on both devices.		
			DIP-switch 1: Compression Options	OFF (up) – Standard compression level. ON (down) – High compression level for additional range extension.	
			DIP-switch 2: Compression Setup	OFF (up) – Enable compression (mandatory). ON (down) – For future use.	
6	D I 45 Connector	PT-871xr OUT	Connect to the DGKat-2.0 IN connector on the PT-872xr using twisted pair cable.		
		PT-872xr IN	Connect to the DGKat-2.0 OUT connector on the PT-871xr using twisted pair cable.		
7	12V DC Connector		Connect the power adapter to one of the devices.		

# Step 3: Install the PT-871xr, PT-872xr

Install PT-871xr, PT-872xr using one of the following methods:

- Attach the rubber feet and place the unit on a flat surface.
- Fasten a bracket (included) on each side of the unit and attach it to a flat surface (see www.kramerav.com/downloads/PT-871xr).
- Mount the unit in a rack using the recommended rack adapter (see <a href="https://www.kramerav.com/product/PT-871xr">www.kramerav.com/product/PT-871xr</a>).






- Avoid uneven mechanical loading.
- Appropriate consideration of equipment nameplate ratings should be used for avoiding overloading of the circuits.



# Step 4: Connect the inputs and outputs

Always switch OFF the power on each device before connecting it to your PT-871xr, PT-872xr.





To achieve specified extension distances, use the recommended Kramer cables to connect AV equipment to the PT-871xr, PT-872xr (available at <a href="www.kramerav.com/product/PT-871xr">www.kramerav.com/product/PT-871xr</a>).

Using third-party cables may cause damage!

# Step 5: Connect the power

Connect the power cord to PT-871xr, PT-872xr and plug it into the mains electricity.

Safety Instructions (See  $\underline{\text{www.kramerav.com}}$  for updated safety information)

• For products with relay terminals and GPI\O ports, please refer to the permitted rating for an external connection, located next to the terminal or in the User Manual.

There are no operator serviceable parts inside the unit.

- Warning:

  Use only the power cord that is supplied with the unit.

  Warning:

  Use only the power cord unplies the unit from the warning conduction.
- Use only the power cord that is supplied with the unit.
  Disconnect the power and unplug the unit from the wall before installing.

# **Step 6: Technical Specifications**

PT-871xr		
Inputs	1 HDMI	On a female HDMI connector
Outputs	1 DGKAT 2.0	On a female RJ-45 connector
PT-872xr		
Inputs	1 DGKAT 2.0	On a female RJ-45 connector
Outputs	1 HDMI	On a female HDMI connector
General		
Video	Transmitted Data Bandwidth	Up to 18Gbps (6Gbps per graphic channel)
	Max Resolution	3840x2160@60Hz (4:4:4) 24bpp at high compression level 4096x2160@60Hz (4:4:4) 24bpp at standard compression level
	Compliance	HDMI 2.0, HDCP 2.2, HDR 10
Reach Extension	Standard Compression Level	Up to 40m (130ft) at 4K@60Hz (4:4:4) Up to 70m (230ft) at 4K@60Hz (4:2:0) or full HD (1080p @60Hz 36bpp)
	High Compression Level	Up to 60m (200ft) at 4K@60Hz (4:4:4) Up to 70m (230ft) at 4K@60Hz (4:2:0) or full HD (1080p @60Hz 36bpp)
Controls	Front Panel	IN, OUT and ON LEDs
	Rear Panel	DIP-switches
Power	Consumption	12V DC, 600mA
	Source	12V DC, 2A
<b>Environmental Conditions</b>	Operating Temperature	0° to +40°C (32° to 104°F)
	Storage Temperature	-40° to +70°C (-40° to 158°F)
	Humidity	10% to 90%, RHL non-condensing
Regulatory Compliance	Safety	CE, UL
	Environmental	RoHs, WEEE
Enclosure	Size	Pico Tool
	Туре	Aluminum
	Cooling	Convection Ventilation
Accessories	Included	1 Power adapter, 1 power cord
Specifications are subject to ch	nange without notice at <u>www.kram</u>	nerav.com

